## ASSEMBLY INSTRUCTIONS

1) Use the provided bamboo rods to hold the threaded collar in place as below.



3) Screw on the shade ring to clamp around the bamboo rods and secure in place.

2) Ensure bamboo rods sit flush with the underside of the collar.



4) Your pendant is now ready to be installed by an electrician.







## papaya