



FINISH: NATURAL OAK

MATERIALS: Solid oak edges with engineered oak veneer panels and black powder-coated metal



coffee table
TAB274




round side table
TAB273



side table w drawer
TAB273



rectangular side table
TAB273



entertainment unit
SHV030




4-shelf - tall
TAB273



3-shelf unit
TAB273



2-shelf console
TAB273



PRODUCT CARE

Wood is a porous material so avoid spills, particularly oils, red wine and pigment rich substances. Even condensation on the base of a glass can leave a ring mark that is difficult to remove. We recommend using placemats, coasters, trivets, tablecloths etc to help protect the surface. These also provide protection against scratches. Hot or cold objects can also affect the timber surface by interacting with the top layer of timber.

PREVENTATIVE CARE

Wipe spills immediately. Regular cleaning and dusting will help keep timber in its best condition. A damp cloth and mild soap can be used as required. Do not use bleach, acidic cleaners, or abrasive cleaning products. Application of Sure Seal Timber Sealer or similar can create a barrier to avoid stains penetrating the top layers of the timber. Follow instructions on pack carefully as incorrect application voids your warranty. Re-apply every 4-6 months.



FINISH: BLACK OAK

MATERIALS: Solid oak edges with engineered oak veneer panels and black powder-coated metal



coffee table
TAB327



round side table
TAB328



side table w drawer
TAB326



rectangular side table
TAB325



entertainment unit
SHV032



4-shelf - tall
SHV031



3-shelf unit
SHV024



2-shelf console
TAB329



H48cm

D44cm



H38cm

D90cm




H50cm

50x45cm




H50cm

50x45cm




H63cm

100x35cm




H45cm

152x36cm



H63cm

150x36cm



H135cm

100x35cm

PRODUCT CARE

Wood is a porous material so avoid spills, particularly oils, red wine and pigment rich substances. Even condensation on the base of a glass can leave a ring mark that is difficult to remove. We recommend using placemats, coasters, trivets, tablecloths etc to help protect the surface. These also provide protection against scratches. Hot or cold objects can also affect the timber surface by interacting with the top layer of timber.

PREVENTATIVE CARE

Wipe spills immediately. Regular cleaning and dusting will help keep timber in its best condition. A damp cloth and mild soap can be used as required. Do not use bleach, acidic cleaners, or abrasive cleaning products. Application of Sure Seal Timber Sealer or similar can create a barrier to avoid stains penetrating the top layers of the timber. Follow instructions on pack carefully as incorrect application voids your warranty. Re-apply every 4-6 months.