

ARCHER



CHA109b
dining chair
42x52xH80cm

seat height
approx. 46cm



CHA109n
dining chair
42x52xH80cm

seat height
approx. 46cm



CHA109w
dining chair
42x52xH80cm

seat height
approx. 46cm



CHA135b
bar stool
43x51xH87cm

seat height
approx. 67cm



CHA135b
bar stool
43x51xH87cm

seat height
approx. 67cm



CHA135b
bar stool
43x51xH87cm

seat height
approx. 67cm

MATERIALS

Legs
Seat

Solid oak veneer

Moulded timber construction with painted/natural oak veneer

All finished with a clear matte polyurethane finish for additional protection

PRODUCT CARE

We recommend using a pH-neutral soap and water mix to clean periodically. Always ensure furniture is dried completely and that no soap residue remains on the surface.

Do not use cleaners or cleaning agents that are abrasive, caustic or acidic such as bleach or ammonia as these may affect the colour of the timber.

PROTECTION

Use a natural multipurpose furniture wax to help to maintain the surface. Always refer to the manufacturer's instructions before use. This advice does not constitute a guarantee. Always check with Papaya before beginning a repair process. Keep out of direct sunlight. For indoor use only.