





BENSON DINING TABLE



OAK - NATURAL
MATERIAL: Solid Oak



small
TAB393



large
TAB384

PRODUCT CARE

Wood is a porous material so avoid spills, particularly oils, red wine and pigment rich substances. Even condensation on the base of a glass can leave a ring mark that is difficult to remove. We strongly recommend using placemats, coasters, trivets, tablecloths etc to help protect the surface. These also provide protection against scratches. Hot or cold objects can also affect the timber surface by interacting with the top layer of timber.

Timber expands or contracts in changing temperatures so protect from direct sunlight to avoid warping and discolouration.

Wipe spills immediately. Regular cleaning and dusting will help keep timber in its best condition. A damp cloth and mild soap can be used as required. Do not use bleach, acidic cleaners, or abrasive cleaning products.

PREVENTATIVE CARE

Application of Sure Seal Timber Sealer or similar can create a barrier to avoid stains penetrating the top layers of the timber. Follow instructions on pack carefully as incorrect application voids your warranty. Re-apply every 4-6 months.