





KENT CHAIR - HAND WOVEN



**FINISH:** BLACK  
**FRAME:** Solid oak  
**SEAT:** Coated paper cord



dining chair  
**CHA241**



dining chair w arms  
**CHA242**



occasional chair  
**CHA243**



counter stool  
**CHA244**

**PRODUCT CARE**

Wipe spills immediately. Regular cleaning and dusting will help keep timber in its best condition. A damp cloth and mild soap can be used as required. Do not use bleach, acidic cleaners, or abrasive cleaning products. For paper cord, wipe clean with a tightly wrung soft cloth to remove any dust or dirt. It is not recommended to do this too often, as it can cause wear to the paper cord.

**PREVENTATIVE CARE**

Application of Sure Seal Timber Sealer or similar can create a barrier to avoid stains penetrating the top layers of the timber. A cushion on the seat is recommended to prolong the life of the paper cord. Coloured clothing or fabrics could stain the natural paper cord if comes in contact with moisture. Being a natural material, humidity and daylight may change the colour of the paper cord and create natural patina.